

Use Watson Language Translator and Watson Text to Speech capabilities

Now that you have added the Watson Language Translator and Watson Text to Speech, you can use them in your application

- Go to your application's node-red editor
- Copy and import this flow into the editor. (Follow the steps described in the previous lab to import from the clipboard)

```
{["id":"4ce623d6.c0d104","type":"ibmiot
in","z":"5b951349.5f9094","authentication":"quickstart","apiKey":"","inputType":"evt","deviceI
d":"8bf9b82ad2fd","applicationId":"","deviceType":"+","eventType":"+","commandType":"","fo
rmat":"json","name":"IBM IoT App
In","service":"quickstart","allDevices":false,"allApplications":false,"allDeviceTypes":true,"allEve
nts":true,"allCommands":false,"allFormats":false,"x":196.66665649414062,"y":250,"wires":[["b
3ad3ec8.deffc8","56fb2f69.10482","6e03d7b1.10c248","1869b46f.f26c54"]]},{"id":"acf5a0d4.9
b4c18","type":"function","z":"5b951349.5f9094","name":"temp","func":"return
{payload:msg.payload.d.temp};","outputs":1,"x":386.6666564941406,"y":250,"wires":[["4d3ffe
dc.cca1d","8c307eb4.e2309"]]},{"id":"4d3ffedc.cca1d","type":"switch","z":"5b951349.5f9094","
name":"temp
thresh","property":"payload","rules":[{"t":"lte","v":40,"v2":null},{"t":"gt","v":40,"v2":null}], "che
ckall":"true","outputs":2,"x":546.6666564941406,"y":250,"wires":[["e2527562.915778"],["8b4a
8e30.d73348"]]},{"id":"c9c52810.f7e22","type":"debug","z":"5b951349.5f9094","name":"cpu
status","active":true,"complete":"false","x":950,"y":226.66668701171875,"wires":[]}, {"id":"b3a
d3ec8.deffc8","type":"debug","z":"5b951349.5f9094","name":"device
data","active":false,"console":"false","complete":"true","x":202.6666259765625,"y":340,"wires
":[]}, {"id":"e2527562.915778","type":"template","z":"5b951349.5f9094","name":"safe","fieldTy
pe":"msg","syntax":"mustache","template":"Temperature ({{payload}}) within safe
limits","x":706.6666564941406,"y":230,"wires":[["abfa2eb7.344af8"]]}, {"id":"8b4a8e30.d73348
","type":"template","z":"5b951349.5f9094","name":"danger","template":"Temperature
({{payload}})
critical","x":715,"y":303.3333435058594,"wires":[["abfa2eb7.344af8"]]}, {"id":"5b3ba89f.b4ada
","type":"comment","z":"5b951349.5f9094","name":"Temperature
Monitor","info":"","x":206.66665649414062,"y":150,"wires":[]}, {"id":"b7ffa894.0ed42","type":"
comment","z":"5b951349.5f9094","name":"Configure
source","info":"","x":196.66665649414062,"y":210,"wires":[]}, {"id":"8c307eb4.e2309","type":"
ui_gauge","z":"5b951349.5f9094","name":"Temperature","group":"2514bb7e.085e3c","order":
0,"width":3,"height":3,"gtype":"gage","title":"Gauge","label":"units","format":"{{value}}",
"min":0,"max":100,"colors":["#00b500","#e6e600","#ca3838"],"seg1":"","seg2":"","x":622.499
9389648438,"y":149.99996948242188,"wires":[]}, {"id":"56fb2f69.10482","type":"function","z":
"5b951349.5f9094","name":"Humidity","func":"return
{payload:msg.payload.d.humidity};","outputs":1,"noerr":0,"x":381.6666259765625,"y":186.666
```

```
65649414062,"wires":[[{"id":"2495eca0.e56034"}]],{"id":"6e03d7b1.10c248","type":"function","z":"5b951349.5f9094","name":"Object Temperature","func":"return {payload:msg.payload.d.objectTemp};","outputs":1,"noerr":0,"x":390,"y":109.99999237060547,"wires":[[{"id":"7abd05e1.5e624c"}]],{"id":"7abd05e1.5e624c","type":"ui_gauge","z":"5b951349.5f9094","name":"Object Temperature","group":"2514bb7e.085e3c","order":0,"width":3,"height":3,"gtype":"gage","title":"Gauge","label":"","C","format":"{{value}}","min":0,"max":100,"colors":["#00b500","#e6e600","#ca3838"],"seg1":"","seg2":"","x":641.6666259765625,"y":54.99999237060547,"wires":[]},{"id":"2495eca0.e56034","type":"ui_gauge","z":"5b951349.5f9094","name":"Humidity","group":"2514bb7e.085e3c","order":0,"width":3,"height":3,"gtype":"gage","title":"Gauge","label":"%", "format":"{{value}}","min":0,"max":100,"colors":["#00b500","#e6e600","#ca3838"],"seg1":"","seg2":"","x":608.3333129882812,"y":103.33333587646484,"wires":[]},{"id":"abfa2eb7.344af8","type":"watson-translator","z":"5b951349.5f9094","name":"","action":"translate","basemodel":"ar-en","domain":"conversational","srclang":"en","destlang":"es","password":"","custom":"","domainhidden":"conversational","srclanghidden":"en","destlanghidden":"es","basemodelhidden":"","customhidden":"","filetype":"forcedglossary","trainid":"","lgparams2":true,"ldparamshidden2":"true","x":884.1666259765625,"y":278.3333435058594,"wires":[[{"id":"c9c52810.f7e22","e11a4b79.a300c"}]],{"id":"f7ad6cb1.9f9e7","type":"httpin","z":"5b951349.5f9094","name":"","url":"/audio","method":"get","swaggerDoc":"","x":173.33331298828125,"y":498.00000762939453,"wires":[[{"id":"caac0040.7c6538"}]],{"id":"b7e5914.2cbe8f","type":"httpresponse","z":"5b951349.5f9094","name":"","x":593.8788013458252,"y":496.2726936340332,"wires":[]},{"id":"caac0040.7c6538","type":"template","z":"5b951349.5f9094","name":"","field":"payload","fieldType":"msg","syntax":"mustache","template":"<!DOCTYPE html>\n<html>\n<head>\n  <title>IBM Watson - Text To Speech</title>\n  <script src=\"https://ajax.googleapis.com/ajax/libs/jquery/2.1.4/jquery.min.js\"></script>\n  \n  <script type=\"text/javascript\">\n    var socketaddy = \"ws://\" + window.location.host + \"/ws/audio\";\n    \n    $(document).ready(function(){\n      var output = document.getElementById('output')\n      $('#output').on('playing', function () {\n        $('#text').text('Playing audio.').\n        \n      });\n      $('#output').on('ended', function () {\n        $('#text').text('Waiting for audio...').\n        \n      });\n      sock = new WebSocket(socketaddy);\n      sock.onopen = function(){\n        $('#text').text('Waiting for audio...');\n        console.log(\"Connected websocket\");\n      }; \n      sock.onerror = function(){\n        console.log(\"Websocket error\");\n      }; \n      sock.onclose = function () {\n        $('#text').text('Not connected. Refresh the page?')\n      }\n      sock.onmessage = function(evt){\n        console.log(\"Websocket message\", evt);\n        output.src = window.URL.createObjectURL(evt.data);\n        output.play();\n      }; \n    });\n  </script>\n  \n</head>\n<body style=\"font-size: 56px; font-family: helvetica; text-align: center; margin-top: 100px;\">\n  <div id=\"text\">Connecting...</div>\n  <audio id=\"output\"></audio>\n</body>\n</html>","x":388.33331298828125,"y":494.9999771118164,"wires":[[{"id":"b7e5914.2cbe8f"}]],{"id":"e11a4b79.a300c","type":"watson-text-to-speech","z":"5b951349.5f9094","name":"","lang":"es-ES","langhidden":"es-ES","voice":"es-ES_LauraVoice","voicehidden":"","format":"audio/wav","password":"","x":806.6666259765625
```

```
, "y":375, "wires":[["2acd737f.e5f534"]]}, {"id":"52ee8814.45042", "type":"websocket
out", "z":"5b951349.5f9094", "name":"","server":"b1117a4b.d507d", "client":"","x":1060.757568
359375, "y":367.72723388671875, "wires":[]}, {"id":"2acd737f.e5f534", "type":"function", "z":"5b
951349.5f9094", "name":"Transform Text to Speech", "func":"msg.payload =
msg.speech;\nreturn
msg;", "outputs":1, "noerr":0, "x":949.48486328125, "y":439.54534912109375, "wires":[["52ee88
14.45042"]]}, {"id":"1869b46f.f26c54", "type":"delay", "z":"5b951349.5f9094", "name":"","pauseT
ype":"rate", "timeout":"5", "timeoutUnits":"seconds", "rate":"1", "nbRateUnits":"10", "rateUnits":
"second", "randomFirst":"1", "randomLast":"5", "randomUnits":"seconds", "drop":true, "x":369, "y
":319.5, "wires":[["acf5a0d4.9b4c18"]]}, {"id":"2514bb7e.085e3c", "type":"ui_group", "z":"","nam
e":"Simulated Sensor
Readings", "tab":"7cdbf1bd.089bc", "disp":true, "width":"6"}, {"id":"b1117a4b.d507d", "type":"we
bsocket-
listener", "path":"/ws/audio", "wholemsg":"false"}, {"id":"7cdbf1bd.089bc", "type":"ui_tab", "z":"","
", "name":"Home", "icon":"dashboard"}]
```

- Go to ibm.biz/iotsensor on a separate browser tab. Copy the device ID.
- Switch back to the Node-Red editor
- Double click the “IBM IoT App in” node. Paste the device ID.
- Double click the “language translator” node. Make changes as in the screenshot to translate from English to Spanish. Click “Done”.

Edit language translator node

Delete

Cancel

Done

Name	<input type="text" value="Name"/>
Mode	<input type="text" value="Translate"/>
Domains	<input type="text" value="Conversational"/>
Source	<input type="text" value="English"/>
Target	<input type="text" value="Spanish"/>
Parameters	<input checked="" type="checkbox"/>
Scope	Not using translation utility

Note: When **not** using the language translation utility to set credentials then 'Not using translation utility' must be checked, else credentials will not be found.

- Click Deploy.
- You should now see the debug panel containing messages in Spanish every 10 seconds.
- Set your laptop speaker volume up. Go to <YourAppName>.mybluemix.net/audio
- You should now here the message spoken to you in Spanish every 10 seconds.